


Scope Items for Golf Course Paving around Pro Shop

1. Raise existing box inlet. Slope new asphalt for drainage.
2. Mill existing asphaltic surface level. Remove loose debris. Apply tack coat throughout for 2" Type D HMA overlay
3. Cut 6' extension (Cut A) and haul off spoil. Provide and compact sub-base as necessary in this area. Pave with 5" of HMA
4. Cut 10' extension (Cut B) and haul off spoil. Provide and compact sub-base in this area as necessary. Pave with 5" of HMA.
5. Cut contoured extension (Cut C) and haul off spoil. Provide and compact sub-base in this area as necessary. Pave with 5" of HMA to tie in to existing parking lot.
6. Install 6" Ribbon Edge Curb bordering planters and putting green.




Scope Item 2



Scope Items 3, 4, 5 – 3" Type B, 2" Surface Course
Type D HMA




6" Ribbon Edge Curb






Remove/Reinstall fence after paving.



B



Tie in to existing asphalt parking lot

C

